

SWN-PS (+)

Standard Sensor

Installation Manual



Contact Information:

Halogen Systems
8985 Double Diamond Pkwy
Suite B10
Reno, NV 89521
Phone: +1 (775) 832-0495

Critical Safety Information




NOTICE

The manufacturer is not responsible for any damages due to misapplication or misuse of this product including, without limitation, direct, incidental, and consequential damages, and disclaims such damages to the full extent permitted under applicable law. The user is solely responsible to identify critical application risks and install appropriate mechanisms to protect processes during a possible equipment malfunction.

Please read this entire manual before unpacking, setting up or operating this equipment. Pay attention to all danger and caution statements. Failure to do so could result in serious injury to the operator or damage to the equipment.

Make sure that the protection provided by this equipment is not impaired. Do not use or install this equipment in any manner other than that specified in this manual.

Use of hazard information

	DANGER
Indicates a potentially or imminently hazardous situation which, if not avoided, will result in death or serious injury	
	WARNING
Indicates a potentially or imminently hazardous situation which, if not avoided, could result in death or serious injury.	
	CAUTION
Indicates a potentially hazardous situation that may result in minor or moderate injury.	

Contents

1	Product Description.....	4
1.1	FEATURES	4
1	Sensor Installation.....	5
1.3	Assembly Overview	5
2	Cable Gland Installation Instructions	7
3	Limited Warranty	8
4	Revision History.....	10
5	Operation and Maintenance Manual.....	10

1 Product Description

SWN-PS (+) sensor model line is a side stream configuration that is designed for installation with a chamber assembly (CHM) and mounting clamps. This sensor configuration includes E-SWN-PS+, SWN-PS+, and SWN-PS model number designations.

An optional Hot Tap version is also available for direct pipe installations.

1.1 FEATURES

- Measures TRO in samples with pH as high as 8.5
- Requires minimal maintenance
- No membranes or electrolyte replacement required
- No waste stream and flow independent
- Direct pipe insertion
- Self-cleaning
- Accurately measure Total Residual Oxidizer in a wide range of water conditions (See Operation and Maintenance Manual via QR for complete specifications)

1 Sensor Installation



DANGER

Multiple hazards. Only qualified personnel must conduct the tasks described in this section of the document. Make sure ballast pipe isolation valves are closed and the ballast pipe is drained before installation.

The two main components of the TRO System (chamber and sensor) must be mounted separately to ensure adequate clearance for sensor removal. The sensor is not affected by changes in flow rates. The figures below outline ideal sensor installation.

1.3 Assembly Overview



Figure 1: Exploded overview of sensor and chamber assembly.




Figure 2: Sensor ejection port is identified by the engraved line on sensor sleeve. This line must be aligned with the engraved outlet line on the chamber during installation.




Figure 3: Optimize sensor operation by aligning the ejection port with the chamber water outlet.

2 Cable Gland Installation Instructions

Ensure that there is a switch or disconnect to power down the system as necessary. It is recommended to use low voltage instrumentation cable with 4 conductors and braided shield such as Tricab 4c1mm2.

Feed-Through (-FE)




 A close-up photograph showing a cable with a braided shield being inserted into a cable gland. The braided shield is exposed and makes contact with the metal housing of the gland.	<p>Option 1 - Partial Jacket Stripping:</p> <ul style="list-style-type: none">• Expose shield approximately 7/16" (10 mm)• Insert cable into fitting until the foil or braid reaches the contact position• Tighten the dome nut• Finished
 A close-up photograph showing a cable with a braided shield being inserted into a cable gland. The outer jacket has been completely removed, and the braided shield is exposed and in contact with the metal housing.	<p>Option 2 - Total Jacket Removed:</p> <ul style="list-style-type: none">• Remove cable jacket to expose the braid or foil• Insert cable into fitting until the braid reaches the contact point• Tighten the dome nut• Finished
 A close-up photograph showing a cable with a braided shield being inserted into a cable gland. The braided shield is folded back over the outer jacket and is in contact with the metal housing.	<p>Option 3 - Fold Shield over Jacket:</p> <ul style="list-style-type: none">• Strip cable jacket & braiding to different lengths• For smaller cable diameters fold the braided shield back over the cable jacket• Insert cable into fitting until the braid reaches the contact point• Tighten the dome nut• Finished

Figure 4: Cable Gland Installation Instructions

Sensor Module wiring note: the shield or external cable shield should contact the metal cable gland on the sensor module, which in turn, will provide contact to the metal sensor housing. If there is no external shield or armor, then the shield should be exposed on the cable by removing the outer insulation jacket (Cable gland on Sensor only). This procedure is described in Figure 6.

3 Limited Warranty

Halogen Systems warrants its products against material workmanship defects for a period of one year from the date of shipment

In the event a defect is discovered during the warranty period, Halogen Systems agrees, at its option, to repair or replace the defective product. Any product repaired or replaced under this warranty will be warranted only for the remainder of the original product warranty period.

Products may not be returned without authorization from Halogen Systems. To obtain authorization, please call Halogen Systems for a return material authorization number.

Limitations:

This warranty does not cover:

- 1) Damage caused by misuse, neglect (lack of appropriate maintenance), alteration, accident, or improper application or installation.
- 2) Damage caused by any repair or attempted repair not authorized by Halogen Systems.
- 3) Any product not used in accordance with the instructions furnished by Halogen Systems.
- 4) Damage caused by acts of God, natural disaster, acts of war (declared or undeclared), acts of terrorism, work actions, or acts of any governmental jurisdiction.
- 5) Freight charges to return merchandise to Halogen Systems.
- 6) Travel fees associated with on-site warranty repair.

This warranty is the sole expressed warranty made by Halogen Systems in connection with its product. All other warranties, whether expresses or implied, including without limitation, the

warranties of merchantability and fitness for a particular purpose, are expressly disclaimed.

The liability of Halogen Systems shall be limited to the cost of the item giving rise to the claim. In no event shall Halogen Systems be liable for incidental or consequential damages.

This warranty is the sole and complete warranty for Halogen Systems. No person is authorized to make any warranties or representations on behalf of Halogen Systems.

Halogen Systems reserves the right to change or modify this warranty at any time.

4 Revision History

Version	Date	Description
IM SWN-PS+ R1.001	8/25/22	Initial Release
IM SWN-PS+ R1.002	9/13/22	Installation images and descriptions updated to reflect chamber and sensor outlet markings. QR link to Ballast QR OM Manual added. TRO measurement range updated to 0 to 20 ppm.
IM SWN-PS+ R1.003	2/23/23	Specifications section removed and reference to OM Manual added. Part numbers updated to reflect customer specific parts.

5 Operation and Maintenance Manual

